

REPLACEMENT SHEET



Fig. 1




Fig. 2





Fig. 3



REPLACEMENT SHEET

Fig. 4A






Fig. 4B



314

Fig. 5



REPLACEMENT SHEET

Fig. 6

Key Switch	Label	Instruction Signal
Key 13a	Store	Keyboard "Ctrl" + "S"
Key 13b	Select All	Keyboard "Ctrl" + "A"
Key 13c	Copy	Keyboard "Ctrl" + "C"
Key 13d	Cut	Keyboard "Ctrl" + "X"
Key 13e	Paste	Keyboard "Ctrl" + "Y"
Key 13f	Undo	Keyboard "Ctrl" + "Z"
Key 13g	Font Setting	Keyboard "Ctrl" + "D"
Key 13h	Create Newly	Keyboard "Ctrl" + "N"
Key 13i	Switch Display	Keyboard "Alt" + "Esc"
Key 13j	On/Off	On/Off Switching Of Input Device

REPLACEMENT SHEET

Fig. 7A




Fig. 7C




Fig. 7B





Fig. 7D



REPLACEMENT SHEET

Fig. 8C




Fig. 8D




Fig. 8A






Fig. 8B



REPLACEMENT SHEET

Fig. 8E



REPLACEMENT SHEET

Fig. 9A




Fig. 9B

